

PlumbingSupply.com – TOP SCREW STYLE – Installation instructions for: J-9141 J9147

- 1) Remove the screw from the front of the handle.
- 2) Pull the handle lever off of the stem and slide the arm and stem out from the handle-base.
- 3) You should now have the handle assembly in 3 pieces, and a screw. Unthread the brass nut from the handle base and remove the brass washer.
- 4) From outside the tank: Insert the handle base into hole in the toilet tank. Make sure the rubber washer is flat against the handle base, and the arm-stop is aligned so the the arm will rest in the correct position.
- 5) From inside the tank: Place the brass washer and the brass nut on the threads of the handle base and tighten until snug.

→ IMPORTANT: DO NOT OVER TIGHTEN - Overtightening may crack the tank!

- 6) Pick up the arm with the handle stem, and insert the stem through the mounting piece from inside the tank. Hold in place.
- 7) Place the handle lever on the stem (as shown in picture). Note, the Stem, and Handle-lever have splines/groves that need to match up, keep the position of the handle in mind when placing it on the stem.
- 8) Insert and tighten the screw into the front of the handle. Test the movement of the lever to make sure its been aligned properly, then test with a flush and make adjustments as needed.

