## PlumbingSupply.com - LEVER STYLE Installation instructions for: J-930 J-933 J-935-xx J-937 J-954 J-9412 J-9148 J-9149 J-9451

## IMPORTANT: DO NOT attempt to remove the screw on the back of the arm. It is not meant to be removed and may break the handle if attempted.

- Unscrew the handle-lever from the round "middle" section
  of the handle. Grasp the handle lever, holding the whole
  assembly with your other hand, turn the lever itself counterclockwise to unscrew it.
- 2) Remove the middle section, and the base of the handle from the handle stem and arm. Then unthread the handle base from the brass mounting piece - this unscrews clockwise. (At this point the entire assembly should be in several pieces.)
- From inside the tank Insert the brass mounting piece only into hole in the tank with the arm-stop(s) positioned so that the arm will rest horizontally.
- 4) From outside the tank Thread the handle base only into the hole in the toilet tank and the brass mounting piece.
- \*\* DO NOT OVER TIGHTEN Over tightening can easily crack the tank \*\*\*
- 5) Insert the handle stem through the mounting piece from inside the tank.
- 6) Place the middle piece of the handle body on the stem with the hole(s) on the side aligned to accept the handle-lever (as shown in picture). Insert the stem of the lever into the middle piece and tighten until snug.
- 7) Test the movement of the lever to make sure its been aligned properly, then attach the flapper chain and test with a flush. Make adjustments as needed.
  Tip: If needed, the flat brass arm can be bent \*slightly\* toward the front or back of the tank as needed; its recommended that you do this prior to the final installation of the arm.

